

6000 Range Powder Extinguishers



features of the model

- **Reliable in operation**
- **High fire-smothering power**
- **Effective on most types of fire**
- **Easy to aim discharge**
- **Safe for use on electrical equipment**
- **No internal corrosion risk**
- **Low temperature operation to -30C**
- **Suitable for tropical use**

specifications

	6044	6066	6099
Content	4 kg	6 kg	9 kg
Operation pressure	15.0 bar	15.0 bar	15.0 bar
Range of discharge	4-6 metres	5-7 metres	5-8 metres
Duration of discharge	15.5 sec	17 sec	19.5 sec
Height	480mm	520 mm	590 sec
Weight	7.5 kg	10.1 kg	14.2 kg
Fire rating	34 A 233 B	43 A 233 B	55 A 233 B

MAINTENANCE

Regular maintenance is necessary for all mechanical articles. It is recommended that all extinguishers should be inspected regularly and be serviced *annually* by a *competent* person. Equipment is supplied subject to our standard Conditions of Sale.

DESCRIPTION

These extinguishers are powder based stored pressure extinguishers. The operating lever is fitted to the brass valve assembly, as is the carrying handle.

Squeezing the lever activates these extinguishers, it opens the valve allowing discharge of the contents via the diptube, hose and nozzle.

METHOD OF OPERATION

1. Use upright, pull out clip
2. Squeeze lever
3. Aim at base of fire



nu-swift

Nu-Swift International Ltd.
Whistons Lane, Elland
West Yorkshire FX5 9DS
tel: 01422 372 852
fax: 01422 314 311
email: customer.service@nuswift.co.uk
web: www.nuswift.co.uk